




Type(s)

Project

Date

Notes

GENERAL INFORMATION

Concert is a software configuration tool for ETC Net3 and RDM capable devices. Concert provides an easy-to-use interface that allows for simple and advanced configuration of a complete lighting control system, all from a single application. In addition to complete system configurations, Concert allows for individual device configurations to be retrieved, saved and uploaded to the system or an individual device at any time.

APPLICATIONS

- Performing Arts Centers
- University Theaters
- Touring Productions
- Educational Theaters
- Conference Centers
- Houses of Worship
- Museums
- Casinos
- Ballrooms

MINIMUM COMPUTER REQUIREMENTS

- PC
 - Windows 7/8/10 (any full version)
 - 2GHz processor (dual or quad core recommended)
 - 1 GB RAM (2 GB or more recommended)
 - Screen resolution of 1280 x 1024 or higher
 - Support for OpenGL
 - Ethernet port
 - Keyboard, mouse and monitor, USB port (to use Gadget for RDM device configuration)
- Mac
 - OS X Mojave (v10.14.3) or later
 - 2.0 GHz Multi-core processor or higher
 - 512 MB RAM minimum
 - Screen resolution of 1280 x 1024 or higher
 - Ethernet port
 - Keyboard, mouse and monitor, USB port (to use with Gadget for RDM device configuration)

ORDERING INFORMATION

Product

MODEL	DESCRIPTION
Concert	Concert Configuration Software

Compatible Products

Net3 Conductor Network Services Gateways
Gadget II
ETC One-port DMX/RDM Gateways
ETC Two-port DMX/ RDM Gateways
ETC Four-port DMX/ RDM Gateways
Response Show Control Gateways
Sensor3 Power Control Systems
Echo and Sensor IQ Power Control Systems
F-Drive Series Drivers
Unison Paradigm Architectural Control Processors and Servers
Echo Expansion Bridge (PC Only)
Eos and Cobalt Family Consoles

Compatible RDM Products*

ETC Entertainment and Studio Fixtures
ETC and HES Automated Lighting Fixtures
ETC Architectural fixtures
Any RDM-capable device

*RDM configuration requires a ETC DMX/RDM Gateway, or Gadget



SPECIFICATIONS

FEATURES

- Build and edit system configurations in real time when connected to the lighting system
- Make edits to existing or new configurations off-line and upload them to the system at any time
- Save default configurations for an entire lighting system to reset your system to its default state
- Error reporting from any ETC Net3 or RDM device
- Configure any RDM device connected to an ETC Gateway

ENVIRONMENT

- Clipboard functionality for entire objects, settings and text
- Undo and redo functionality
- Auto-backup
- Application interface based around a tree-view, a workspace area, a property editor and item selector
- Data representation in graphical workspace (plan) or in tabular form (spreadsheet)
- Plan views support zoom
- Plan views support a layout and snap-to-grid functionality
- The property inspector displays and allows modification properties for a single or multiple objects

SYSTEM CONFIGURATION

- Add devices by selection from a library or by automatic discovery
- Topographical Network Map created by automatic discovery of all online devices
- View all devices that make up a system network in a World View or create Logical Systems to contain a subset of devices
- Configuration mini-editor shall be displayed for any device
- Arrange items displayed on the plan using drag-and-drop interaction
- Import images as backgrounds for the plan view
- It shall be possible to create logical DMX and Ethernet connections between devices
- Discover and configure devices with incorrect network setting using the Unreachable Devices Wizard.

COMPATIBILITY

NET3 CONDUCTOR

- Configure Network Services, including:
 - Address Service (DHCP)
 - Time Service (sNTP)
 - File Transfer Service (FTP)
 - Error and Status Logging
- Configure Windows File-Sharing Services (SMB)
- Configure e-mail notification service

SENSOR3

- Configure Patch, Mode, Curve and advanced properties
- Configure network properties
- Create custom dimmer curves
- Configure and monitor connected loads (AF only)

SENSOR+

- Configure Patch, Mode, Curve and advanced properties
- Configure network properties

DMX/RDM GATEWAYS

- Configure DMX ports
- Set Port address
- Create Advanced Input Patch (AIP)
- Configure network settings

UNISON PARADIGM

- Monitor Status of Processors and Central Control Server
- View Network Settings
- View Error information

RDM CONFIGURATION

- Configure any RDM device connected to an ETC Gateway
- Set Device address and mode remotely
- View onboard sensor information
- Configure manufacturer specific properties
- Identify devices, even if they have the same address



Corporate Headquarters • Middleton, WI USA

Global Offices • London, UK • Rome, IT • Holzkirchen, DE • Paris, FR • Hong Kong

Dubai, UAE • Singapore • New York, NY • Orlando, FL • Los Angeles, CA • Austin, TX

Copyright©2021 ETC. All Rights Reserved. All product information and specifications subject to change. Rev B 2021-02

*Trademark and patent info: etconnect.com/IE

etconnect.com